



BACKFLOW PREVENTER SHOULD BE TESTED AND CERTIFIED AFTER INSTALLATION BY A CERTIFIED BACKFLOW PREVENTER TECHNICIAN.

WRAP ENTIRE ASSEMBLY WITH INSULATION TAPE FOR LIGHT FREEZE PROTECTION. DO NOT BLOCK DRAIN PORTS ON BACKFLOW PREVENTER,

WATER MUST BE ABLE TO DRAIN AWAY FROM DEVICE ONTO GROUND OR INTO A STORM DRAIN OR SEWER.

MOST CODES ALLOW RP DEVICE TO BE INSTALLED IN A BASEMENT IF DRAINAGE IS PROVIDED AND RP UNIT IS AT LEAST 12" ABOVE FLOOR.

TEST COCKS ON RP DEVICE MUST BE ACCESSIBLE TO ALLOW CONNECTION OF TEST UNIT.

*GALV. STEEL PIPE AND FITTINGS MAY BE USED IN SOME CLIMATES. CHECK IF APPROPRIATE LOCALLY . GALV. STEEL WILL REACT WITH THE BRASS B.P. IN MANY CLIMATES RESULTING IN PREMATURE FAILURE.

Use of this drawing is at your own risk. Drawing may not be appropriate for use in all situations or conditions. Check with local authorities for specific requirements of governing codes and ordinances. By use of this drawing you agree in full to the "Terms of Use" found at <http://www.jessstryker.com/legal.htm> as if they were repeated in full here.

IrrigationTutorials.com

The web's mother lode of free irrigation information!

REDUCED PRESSURE BACKFLOW PREVENTER

Not to Scale

SAMPLE PLAN ONLY - NOT FOR CONSTRUCTION